




# Ring

mouse


Quick Start Guide

---

RMWTB200  
RMWTW200



# Component Overview



## Power Button

Press the power button to turn the Ring Mouse on or off.

- To turn on : Press the power button once briefly. The LED will start blinking to indicate the current status of the Ring Mouse.
- To turn off : Press and hold the power button for more than 2 seconds. The LED will blink quickly. Release the button while it is blinking to turn off the device.

## LED

The LED indicator shows the operating status of the Ring Mouse.

- Bluetooth Pairing Mode : The LED blinks slowly.
- Bluetooth Connected : The LED blinks briefly about once every 4 seconds
- Low Battery Warning : The LED blinks twice in quick succession. Please recharge the battery.


## Buttons

Performs button clicks and scroll actions using the Ring Mouse.

- Right Click : Press the R Button
- Left Click : Press the L Button
- Move Pointer : While touching the Move button, move the Ring Mouse. The pointer will follow the movement.
- Scroll : While touching the Scroll button, move the Ring Mouse up or down to scroll. Moving the Ring Mouse left or right performs a Back or Forward action.

## Wearing the Ring Mouse

- Wear the Ring Mouse on your index finger as shown in the image. The power button should face upward (toward the back of your hand), and the curved surface should rest against your middle finger.
- Point your fingertip toward the monitor you wish to control.



# Bluetooth Pairing Instructions

---

## • Device Connection



1. Press the power button once. The LED will blink slowly, indicating that the Ring Mouse is in Bluetooth pairing mode.
  2. On your device's Bluetooth settings screen, select [RingMouse V2.xx] from the list.
  3. The Ring Mouse is now connected and ready for use.
- \* Mac, Android, and iPhone OS devices can be connected using a similar method.

## • Additional Steps for iPhone Users

1. Go to Settings > Accessibility > Touch.
2. Turn on AssistiveTouch.

## • Recommended System Requirements

- Windows 10 or later
- iPadOS 16 or later
- iOS 16 or later
- Bluetooth 4.2 or later

# Mouse Click and Scroll Instructions



## Pointer Movement (Left/Right)

To move the mouse pointer left or right, **touch and hold** the **Move button** while tilting the Ring Mouse in the desired direction. The pointer will stop moving when you release the button.



## Pointer Movement (Up/Down)

To move the mouse pointer up or down, **touch and hold** the **Move button** while moving the Ring Mouse vertically. The pointer will stop moving when you release the button.



## Scroll


To scroll, **touch and hold** the **Scroll button** while moving the Ring Mouse up or down. Scrolling will stop when you release the button.



## Back / Forward

While touching the **Scroll button**, move the Ring Mouse to the left to perform a **Back action**, and move it to the right to perform a **Forward action**.

(Back and Forward actions may not work depending on the OS, program, or app you are using.)



## Left Click / Right Click

To perform a left-click, press the L button. To perform a right-click, press the R button. Double-click by pressing the L button twice quickly. To drag, press and hold the L button while moving the Ring Mouse.

# Product Registration Information

---

## Cautions

Please read this user manual carefully before using the product. Damages caused by improper handling are not covered by the warranty. The use of faulty or uncertified chargers may result in damage that is not covered under warranty.

## Product Information

Product Name	Ring Mouse
Model Name	RMWTB200 (BLACK) RMWTW200 (WHITE)
Size	9g / 39mm x 40mm x 13mm
Specifications	5V / 0.07A, Operating Temperature 10°C ~ 32°C
Bluetooth	Bluetooth 5.1
Frequency	2402MHz ~ 2480MHz (Rx/Tx)
Address	Room 202-1, 169 Gaetbeol-ro, Yeonsu-gu, Incheon, Republic of Korea
Customer Support	Scan the QR Code
FCC ID	2BQZ4-RMWTB200

